




1. THE CONNECTIONS FOR THE INTERFACE
2. FROM THE RADIO'S EXTERNAL SPEAKER TO THE INTERFACE
3. THE ALTERNATIVE DB-9 CONNECTORS TO THE INTERFACE
4. THE AUDIO CONNECTORS FROM THE INTERFACE
5. THE DB-9 TO USB CONNECTION TO A LAPTOP COMPUTER
6. THE TO / FROM AUDIO CONNECTORS TO THE COMPUTER




TRRS to Mic Connector




This is the configuration for the DB-9 to USB Connector showing DB-9 connected to the Interface and the USB connected to a Laptop Computer



Audio Cable from External Speaker of the Radio



Audio Cables To and From Interface to Computer



Interface connected to Laptop with DB-9 to USB cable; Audio To / From Computer to Interface; Radio External Speaker cable to Interface.